




Pressure Drop.

Graph for calculating pressure drop for the Stourflex Type JP501, JP502 & JP503 Nonair Air and Dirt Separators,



Graph for calculating pressure drop for the Stourflex Type JP504 Nonair Air and Dirt Separator with built in strainer

